










































INSTRUCTION MANUAL









PARTS LIST

<p>1</p>  <p>x2</p> <p>Tube - 1 Φ38x440x595mm</p>	<p>2</p>  <p>x2</p> <p>Tube - 2 Φ38x700mm</p>	<p>3</p>  <p>x1</p> <p>Tube - 3 Φ38x860mm</p>	<p>4</p>  <p>x1</p> <p>Tube - 4 Φ38x860mm</p>
<p>5</p>  <p>x1</p> <p>Tube - 5 Φ22x685x640mm</p>	<p>6</p>  <p>x1</p> <p>Tube - 6 Φ22x685x640mm</p>	<p>7</p>  <p>x2</p> <p>Tube - 7 Φ38x285x685mm</p>	<p>8</p>  <p>x2</p> <p>Tube - 8 Φ38x900mm</p>
<p>9</p>  <p>x1</p> <p>Tube - 9 Φ22x670mm</p>	<p>10</p>  <p>x1</p> <p>Tube - 10 Φ22x670mm</p>	<p>11</p>  <p>x2</p> <p>Tube - 11 Φ22x770mm</p>	<p>12</p>  <p>x4</p> <p>Tube - 12 Φ22x770mm</p>
<p>13</p>  <p>x2</p> <p>Tube - 13 Φ38x400mm</p>	<p>14</p>  <p>x1</p> <p>Tube - 14 Φ38x500x1220mm</p>	<p>15</p>  <p>x3</p> <p>Tube - 15 Φ19x1205mm</p>	<p>16</p>  <p>x2</p> <p>Tube - 16 Φ19x1055mm</p>
<p>17</p>  <p>x3</p> <p>Basketball</p>	<p>18</p>  <p>x1</p> <p>Electronic Scorer</p>	<p>19</p>  <p>x2</p> <p>Paddle Sensor</p>	<p>20</p>  <p>x12</p> <p>Plastic Washer M6</p>
<p>21</p>  <p>x2</p> <p>Rim</p>	<p>22</p>  <p>x2</p> <p>Rim Support Plate</p>	<p>23</p>  <p>x1</p> <p>Air Pump</p>	<p>24</p>  <p>x2</p> <p>Rim Net</p>
<p>25</p>  <p>x1</p> <p>Backboard</p>	<p>26</p>  <p>x74</p> <p>M6 Washer</p>	<p>27</p>  <p>x16</p> <p>M6x20mm Bolt</p>	<p>28</p>  <p>x1</p> <p>M6 x35mm Bolt</p>
<p>29</p>  <p>x8</p> <p>M6x75mm Bolt</p>	<p>30</p>  <p>x2</p> <p>M6x65mm Bolt</p>	<p>31</p>  <p>x10</p> <p>M6x50mm Bolt</p>	<p>32</p>  <p>x43</p> <p>M6 Nut</p>
<p>33</p>  <p>x4</p> <p>3.5 x 8mm Bolt</p>	<p>34</p>  <p>x4</p> <p>M6 x 70mm Bolt</p>	<p>35</p>  <p>x1</p> <p>Electronic Scorer Face Plate</p>	<p>36</p>  <p>x1</p> <p>Wrench</p>

37  x2 M6x45mm Bolt	38  x2 Locking Pin	39  x1 Ball Return Net	40  x8 Spacer
41  x1 Allen Key			

PRE-INSTALLED PARTS

P1  x4 Big Spring Lock Cerradura de Resorte Grande	P2  x4 Small Spring Lock Cerradura de Resorte Pequeño	P3  x8 Plastic Pole Insert Φ1-1/2" Encaje de Poste Plástico Φ1-1/2"	P4  x8 Plastic Pole Insert Φ7/8" Encaje de Poste Plástico Φ7/8"
P5  x1 Foam Espuma	P6  x2 Safety Strap Correa de Seguridad		

ASSEMBLY INSTRUCTIONS:

- Find a clean, level place to begin the assembly of your Basketball Game. We recommend that two adults work together to assemble this basketball game.
- Remove all the parts from the box and verify that you have all of the listed parts as shown on the Parts list pages. Carefully cut or tear the four corners of the box so that the bottom of the box can be used as your work surface.






FIG.1 & 2

- Attach the Tubes - 2 (#2) to the Tube - 3 and Tube - 4 (#3 and #4) using the spring lock mechanism (pre-installed) as shown in FIG. 1.
- Attach the Tubes - 7 (#7) to the Tubes - 8 (#8) using the spring lock mechanism (pre-installed) as shown in FIG. 2.




FIG. 3




FIG.3

5. Insert the Tube - 6 (#6) to the Tube - 5 (#5) as shown in FIG. 3.




FIG. 4




FIG.4

6. Attach the Tubes - 12 (#12) to the Tube - 9, Tube - 10 and Tube - 11 (#9, #10 and #11) using the spring lock mechanism (pre-installed) as shown in FIG. 4.




FIG. 5




FIG. 5B

FIG. 5C

FIG. 5A

FIG.5

7. Attach the Tube - 5 and Tube - 6 (#5 and #6) to Tube - 3 and Tube - 4 (#3 and #4) using Bolts (#30), Washers (#26) and Nuts (#32), and then attach the Tube - 5 and Tube - 6 (#5 and #6) to the Tubes - 8 (#8) and Tube - 15 (#15) using Bolts (#31), Washers (#26) and Nuts (#32) as shown in FIG. 5A & 5B.

8. Attach the Tubes - 7 and Tubes - 8 (#7 and #8) to the Tubes - 2 (#2) using Bolts (#31), Washers (#26) and Nuts (#32) as shown in FIG. 5C, repeat this step for other side.

Note: Make sure the spring lock mechanism is face down.




FIG. 6




FIG.6

9. Attach the Tube - 15 and Tubes - 16 (#15 and #16) to Tube - 2 (#2), Tube - 5 (#5) and Tube - 6 (#6) using Bolts (#28 & #31), Washers (#26) and Nuts (#32) as shown in FIG. 6A & 6B.




FIG. 7




FIG.7

10. Insert the Tubes - 1 (#1) to the Tubes - 2 (#2) as shown in FIG. 7.




FIG. 8




FIG.8

11. Insert the Tubes - 14 (#14) to the Tubes - 13 (#13) as shown in FIG. 8.




FIG. 9




FIG.9

12. Attach the Tubes (#9, #10, #11, #12) to Tube - 14 (#14) and Tube - 8 (#8) using Bolts (#29), Washers (#26), Spacers (#40), Locking Pins (#38) and Nuts (#32) as shown in FIG. 9A & 9B.




FIG.10

13. Attach the Rims (#21) and Rim Support Plates (#22) to the Backboard (#25) using the Bolts (#27), Washers (#26) and Nuts (#32). Then attach the Paddle Sensors (#19) to the Backboard (#25) using the Bolts (#27), Washers (#20 & #26) and Nuts (#32). Ensure that washers are used on both sides of the backboard as shown in FIG. 10.




FIG.11

14. Attach the Electronic Scorer Face Plate (#35) to the front of the Backboard and connect with the Electronic Scorer (#18) using Bolts (#33) as shown in FIG. 11.

15. Install the Net (#24) to the Rim (#21) as shown in FIG. 11A and 11B.






15		X 1
26		X 4
32		X 2
37		X 2
39		X 1

FIG.12

FIG.12A

FIG.12B

FIG.12C




FIG.12

16. Slide elastic straps and sleeve of Ball Return Net (#39) onto Top Tubes - 1 (#1) as shown in FIG. 12A & 12B.

17. Slide the Tube - 15 (#15) in front of the Ball Return Net (#39) and attach it to the Tube - 14 (#14) using Bolts (#37), Washers (#26) and Nuts (#32) as shown in FIG. 12C.





20		X 4
26		X 4
32		X 4
34		X 4

FIG. 13




FIG.13

18. With the help of another adult, Attach the Backboard (#25) to the Tubes - 1 (#1) using Bolts (#34), Washers (#20 & #26) and Nuts (#32) as shown in FIG. 13A. At each bottom hole of the backboard, attach the ramp tabs of Ball Return Net (#39) using Bolts (#34), Washers (#20 & #26), and Nuts (#32) as shown in FIG. 13B.

19. Insert the Locking Pins (#38) to the Tube - 8 (#8) as shown in FIG. 13C.

FIG. 14




FIG. 14A




FIG.14

20. Connect the Sensor Wire of Paddle Sensor (#19) to the Electronic Scorer (#18) as shown in FIG. 14.

FIG. 15




FIG.15

21. Folding the basketball game - First remove the Locking Pins (#38). **See FIG. 15A.** Then attach the Safety Straps (#P6) together to prevent the sides from falling. Repeat for the other side. **See FIG. 15B.**

22. To unfold the basketball game - First release the Safety Straps (#P6). Then pull the handle and the bottom of the tube - 13 (#13) , and slowly lower the table to the floor.


ELECTRONIC SCORER OPERATION

Battery Installation

Battery Box: Unscrew the bolt using a screwdriver and open the battery box. Insert 3 "AA" batteries (not included) in the order of polarity as shown on the inside cover. Then close the cover using a screwdriver. Turn the power ON using the ON/OFF switch.

Reminding:

- Batteries must be installed according to the correct polarization (+ and -) required.
- Please clean the battery contacts and also those of the device prior to battery installation.
- If the game will not be used for a long period of time, we recommend that the batteries should be removed.



How to play?

- While game is in Sleep Mode, if a basketball is scored, the game will turn back on and the score board will begin the 5 sec. countdown.
- After finishing the game, Turn OFF the scorer by using the ON/OFF switch. NOTE: The scoreboard will turn off after 5 minutes of inactivity; however, we recommend turning the ON/OFF switch to OFF when the game will not be used for an extended period of time.



WARNING:

- Requires 3 "AA" batteries (not included).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon zinc), or rechargeable (nickel-cadmium) batteries.